

Wiring Diagram: Power H-20, Populus X-1-A, Reader K-1-A, and contactor

This connection is only possible if you connect the Populus directly to the LAN.

Backup battery, 12V 2.3Ah.
Pay attention to the polarity!

