

Connect Rex to the Spider W5 power supply as shown in the diagram with a standard UTP cable.

For distances greater than 25m, use one twisted pair of UTP cable for each pole (+ and -).

The cable length between the power supply and the Rex should not exceed 50m. Connect the Spider W5 to the mains power 110-230V AC with the enclosed power cord.

CONNECTION CABLE

| Wire* | Colour | Description | Spider Connector |
|---------------------------|----------------------------|-------------------|------------------|
| 1 | - Red | 9-14V DC | + |
| 2 | Gray/Black | GND | - |
| 3 | Green | El. strike output | 00 |
| 4 | White | Not connected | O1 |
| 5 | - Yellow | Door switch input | 10 |
| 6 | Orange | Push button input | l1 |
| 7 | Blue | RS-485 CA | CA |
| 8 | - Brown | RS-485 CB | CB |
| * 1. wire is coloured red | | | |

www.jantar.si