1. Press "Win+I" buttons on the keyboard. Win Button:



2. On the menu which appears click on "Change PC settings".



- 3. Click "Update and recovery".
- 4. Click "Recovery".



Refresh your PC without affecting your files

If your PC isn't running well, you can refresh it without losing your photos, music, videos and other personal files.

Get started

Remove everything and reinstall Windows

If you want to recycle your PC or restart completely, you can reset it to its factory settings.

 Get started

Advanced start-up

Start up from a device or disc (such as a USB drive or DVD), change Windows start-up settings or restore Windows from a system image. This will restart your PC.



6. Click "Troubleshoot".



7. Click "Advanced options".



8. Click "Start-up settings".



9. Click "Restart".



9. Press "7" button on the keyboard.



Press Enter to return to your operating system

10. After restarting the PC add the driver for the Reader D-1-USB in Device manager. Follow the manual of the Reader D-1-USB or view the video guide on the jantar.si/forum/en/.